

# CHARGING SYSTEM

System Description

---

## System Description

NFSC0009

The alternator provides DC voltage to operate the vehicle's electrical system and to keep the battery charged. The voltage output is controlled by the IC regulator.

Power is supplied at all times to alternator terminal 3 (S) through:

- 120A fusible link (letter **A**, located in the fuse and fusible link box), and
- 10A fuse (No. 70, located in the fuse and fusible link box).

Terminal B supplies power to charge the battery and operate the vehicle's electrical system. Output voltage is controlled by the IC regulator at terminal 3 (S) detecting the input voltage. The charging circuit is protected by the 120A fusible link.

The alternator is grounded to the engine block.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 30, located in the fuse block (J/B)]
- to combination meter terminal 24 for the charge warning lamp.

Ground is supplied to terminal 68 of the combination meter through terminal 2 (L) of the alternator. With power and ground supplied, the charge warning lamp will illuminate. When the alternator is providing sufficient voltage with the engine running, the ground is opened and the charge warning lamp will go off.

If the charge warning lamp illuminates with the engine running, a fault is indicated.


# CHARGING SYSTEM

Wiring Diagram — CHARGE —

## Wiring Diagram — CHARGE —

NFSC0010



### SC-CHARGE-01



REFER TO EL-POWER.

⬭ : LHD MODELS  
⬮ : RHD MODELS

\* 1 6C : ⬭  
6B : ⬮



REFER TO THE FOLLOWING.  
 (M15) -SUPER  
 MULTIPLE JUNCTION(SMJ)  
 (M19) -FUSE BLOCK-  
 JUNCTION BOX(J/B)

MEL890K

# CHARGING SYSTEM

Trouble Diagnoses

## Trouble Diagnoses


NFSC0011

Before conducting an alternator test, make sure that the battery is fully charged. A 30-volt voltmeter and suitable test probes are necessary for the test. The alternator can be checked easily by referring to the Inspection Table.

- Before starting, inspect the fusible link.
- Use fully charged battery.

### WITH IC REGULATOR

NFSC0011S01



Warning lamp: "CHARGE" warning lamp in combination meter

SEL338V

### NOTE:

- If the inspection result is OK even though the charging system is malfunctioning, check the B terminal connection. (Check the tightening torque.)
- When field circuit is open, check condition of rotor coil, rotor slip ring and brush. If necessary, replace faulty parts with new ones.

### MALFUNCTION INDICATOR



NFSC0011S02

The IC regulator warning function activates to illuminate "CHARGE" warning lamp, if any of the following symptoms occur while alternator is operating:

- Excessive voltage is produced.
- No voltage is produced.

## Construction

NFSC0012



## Removal and Installation

### REMOVAL

1. Remove engine undercover RH.
2. Remove side inspection cover RH.
3. Loosen belt idler pulley.
4. Remove drive belt.
5. Remove A/C compressor mounting bolts (four).
6. Slide A/C compressor forward.
7. Disconnect alternator harness connector.
8. Remove alternator upper bolt and lower bolt.


NFSC0013

NFSC0013S01

### INSTALLATION


To install, reverse the removal procedure.

NFSC0013S02



# CHARGING SYSTEM

## Disassembly



## Disassembly

### REAR COVER

NFSC0021

NFSC0021S01

#### CAUTION:

Rear cover may be hard to remove because a ring is used to lock outer race of rear bearing. To facilitate removal of rear cover, heat just bearing box section with a 200W soldering iron.


Do not use a heat gun, as it can damage diode assembly.

## REAR BEARING

NFSC0021S02

#### CAUTION:

- Do not reuse rear bearing after removal. Replace with a new one.
- Do not lubricate rear bearing outer race.



## Inspection

### ROTOR CHECK

NFSC0022

NFSC0022S01

1. Resistance test


**Resistance: Refer to SDS (SC-26).**

- Not within the specified values ... Replace rotor.
2. Insulator test
  - Continuity exists ... Replace rotor.
  3. Check slip ring for wear.

**Slip ring minimum outer diameter:**

**Refer to SDS (SC-26).**


- Not within the specified values ... Replace rotor.



## BRUSH CHECK

NFSC0022S02


1. Check smooth movement of brush.
  - Not smooth ... Check brush holder and clean.
2. Check brush for wear.
  - Replace brush if it is worn down to the limit line.




## STATOR CHECK

NFSC0022S03

1. Continuity test
  - No continuity ... Replace stator.



2. Ground test
  - Continuity exists ... Replace stator.



## Assembly


NFSC0023

### RING FITTING IN REAR BEARING

NFSC0023S01

- Fix ring into groove in rear bearing so that it is as close to the adjacent area as possible.

**CAUTION:**  
Do not reuse rear bearing after removal.




## REAR COVER INSTALLATION

NFSC0023S02

1. Fit brush assembly, diode assembly, regulator assembly and stator.
2. Push brushes up with fingers and install them to rotor.

**Take care not to damage slip ring sliding surface.**



## SERVICE DATA AND SPECIFICATIONS (SDS)

### Battery

| <b>Battery</b>  |                              |         |            |
|-----------------|------------------------------|---------|------------|
| <i>NFSC0014</i> |                              |         |            |
| Applied model   | VQ20DE                       |         | VQ30DE     |
|                 | Europe and except for Europe |         | For Europe |
| Type            | 55D23L                       | 65D26L  | 80D26L     |
| Capacity V-AH   | 12-48                        | 12 - 52 | 12 - 55    |

### Starter

| <b>Starter</b>   |  |                     |
|--|--|---------------------|
| <i>NFSC0015</i>  |  |                     |
| Type   | S114-801D                                  |                     |
|  | HITACHI make                               |                     |
|  | Reduction gear type                        |                     |
| System voltage   | 12V  |                     |
| No-load  | Terminal voltage                           | 11.0V               |
|  | Current                                    | Less than 90A       |
|  | Revolution                                 | More than 2,700 rpm |
| Minimum diameter of commutator                             | 28.0 mm (1.102 in)                         |                     |
| Minimum length of brush                                    | 10.5 mm (0.413 in)                         |                     |
| Brush spring tension                                       | 12.7 - 17.7 N (1.3 - 1.8 kg, 2.9 - 4.0 lb) |                     |
| Clearance "ℓ" between pinion front edge and pinion stopper | 0.3 - 2.5 mm (0.012 - 0.098 in)            |                     |

### Alternator

| <b>Alternator</b>  |   |
|--|---|
| <i>NFSC0016</i>  |   |
| Type   | LR1100-725B   |
|  | HITACHI make  |
| Nominal rating   | 12V-110A  |
| Ground polarity  | Negative  |
| Minimum revolution under no-load (When 13.5V is applied) | Less than 950 rpm   |
| Hot output current (When 13.5V is applied)               | More than 35A/1,300 rpm<br>More than 83A/2,500 rpm<br>More than 95A/5,000 rpm |
| Regulated output voltage                                 | 14.1 - 14.7V  |
| Minimum length of brush                                  | More than 6.00 mm (0.2362 in)   |
| Brush spring pressure                                    | 1.000 - 3.432 N (102 - 350 g, 3.60 - 12.34 oz)                                |
| Slip ring minimum outer diameter                         | More than 26.0 mm (1.024 in)  |
| Rotor (Field coil) resistance                            | 2.31Ω   |